



# SMART CONNECTABLE

End cap must be secured with gasket.



ART.NR :704711  
Transformer 31V 12Va



TRANSFORMER  
**DOUBLE  
TIMER  
INCLUDED**

ART.NR :704706  
Lightchain 16m Extra



Check the gasket,  
screw the cap until secure


ART.NR :704705  
Lightchain 8m Extra

ART.NR :704709  
5 way connector




ART.NR :704704  
Lightchain 4m Extra

ART.NR :704708  
2 way connector



ART.NR :704699  
Transformer 31V 15Va



TRANSFORMER  
**DOUBLE  
TIMER  
INCLUDED**

Indoor and outdoor use

Never connect this lightchain electrically to other lighting chains!

The bulb of this lighting chain are not replaceable. If the insulation, light bulb or lighting chain is damaged, the lighting chain must not be used and must be discarded!

Do not connect the light chain to the supply while the lighting chain is inside the packing!

The lighting chain could be inter-connect, the total wattage cannot over MAX 12 W (connectable up to 1000 LEDs)

This lighting chain must only be used with the provided transformer.

Plug should not be in socket while installing this product.

An LED starter set is required for connection, or LED product of same series that is connected to an LED starter set.

Warning! This light chain must not be used without all gasket being in place

Do not immerse the light chain into liquid or water.

Please ensure all connection are secured and connection cap screwed tightly with gasket (see above diagram).

End cap of the light chain must be secured with gasket.

Parts are sold seperately.

Regularly remove thick snow on the LED bulb and light chains connectors.



Discarded electric appliances are recyclable and should not be discarded in the domestic waste! Please actively support us in conserving resources and protecting the environment by returning this appliance to the collection centres.

Markslöjd Intertrade AB  
Gränevägen 5 S-511 62 Skene  
Sweden

[www.markslloyd.com](http://www.markslloyd.com)